

---

# How to Clean Your Smoke Alarm

---

## 10 Year Lithium Non-removable Battery Smoke Alarm



**1.**

Use a soft brush or your vacuum to gently remove any dust or debris every six months. In most cases this can be done from the ground.



**2.**

Gently wipe the detector with a soft damp cloth every six months. Always use a ladder appropriate for the job. Never stand on chair or furniture etc. You can clean all types of alarms in this manner.

**NEVER ATTEMPT TO CHANGE A BATTERY IN A 10-YEAR  
NON-REMOVABLE LITHIUM BATTERY ALARM.**

